

LEAD IN PRIORITY AREAS SAMPLE RESULTS 2014
NAVAL SUPPORT FACILITY DAHLGREN

SAMPLING LOCATION DESCRIPTION				INITIAL SAMPLING RESULTS			RE-SAMPLING RESULTS	CORRECTIVE ACTIONS
				CATEGORY	SAMPLE ID	Outlet Description	Comments	
First Draw (ppb)	Retest required?	Date Fixture Secured?	Follow up Flush [Collected 30 seconds after First Draw Sampling (ppb)]					Description
SAMPLING DATE				11/1/2014			11/18/2014	
RESULTS DATE				11/3/2014			11/19/2014	
DRINKING	DH-YAC-RM101-K-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A	
DRINKING	DH-YAC-Bath105-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-YAC-Bath106-HHWA-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-YAC-Bath106-HHWB-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-YAC-Bath107-HHWA-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-YAC-Bath107-HHWA-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-YAC-OUTYard-WFB-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A	
DRINKING	DH-YAC-OUTYard-WS-FD	Water Spigot		non-detect	NO	N/A	N/A	
DRINKING	DH-YAC-HLW105-WFC-FD	Water Fountain Cooler		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM101-LHW-FD	Low Hand Washing Faucet (youth)		4.2	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM101-WFB-FD	Water Fountain (Bubbler)		2.7	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM102-LHW-FD	Low Hand Washing Faucet (youth)		2.7	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM102-WFB-FD	Water Fountain (Bubbler)		4.4	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM104-HHWA-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM104-HHWB-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM105-HHWA-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM105-HHWB-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-HLW106-WFC-FD	Water Fountain (Cooler)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM108-LHWA-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM108-LHWB-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM108-WFB-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM109-LHWA-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM109-LHWB-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM109-WFB-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM110-LHWA-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM110-LHWB-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM110-WFB-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM111-LHWA-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM111-LHWB-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM111-WFB-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM112-WFCA-FD	Water Fountain (Cooler)		5.6	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM112-WFCB-FD	Water Fountain (Cooler)		4.7	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM113-HHWA-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM113-HHWB-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM113-LHWA-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM113-LHWB-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM115-HHW-FD	High Hand Washing		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM116-LHWA-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM116-LHWB-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM118-LHWA-FD	Low Hand Washing Faucet (youth)		3.8	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM118-LHWB-FD	Low Hand Washing Faucet (youth)		1.2	NO	N/A	N/A	
DRINKING	DH-SCHOOL-HLW118-WFCA-FD	Water Fountain (Cooler)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-HLW118-WFCB-FD	Water Fountain (Cooler)		1.3	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM123-HHWA-FD	High Hand Washing (adults)		4	NO	N/A	N/A	

DRINKING	DH-SCHOOL-RM123-HHWP-FD	High Hand Washing (adults)		20	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM123-HHWC-FD	High Hand Washing (adults)		22	Yes	11/10/2014	3.3	Routine Control Measures Only
DRINKING	DH-SCHOOL-RM123-HHWD-FD	High Hand Washing (adults)		6.4	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM124-LHW-FD	Low Hand Washing Faucet (youth)		3	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM124-WFB-FD	Water Fountain (Bubbler)		3	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM125-LHW-FD	Low Hand Washing Faucet (youth)		6.1	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM125-WFB-FD	Water Fountain (Bubbler)		7.3	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM126-LHWA-FD	Low Hand Washing Faucet (youth)		1.8	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM126-LHWP-FD	Low Hand Washing Faucet (youth)		4.2	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM132-HHWA-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM132-HHWP-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM133-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM134-LHWA-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM134-LHWP-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM134-WFB-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-HLW134-WFC-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM121B-HHWA-F	Water Fountain (Cooler)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-Bath121B-HHWP	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM121B-K-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM121B-WFCA-F	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM121B-WFCB-F	Water Fountain Cooler		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM131B-HHWP-F	Water Fountain Cooler		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM131E-HHWA-F	High Hand Washing (adults)		9	NO	N/A	N/A	
DRINKING	DH-SCHOOL-OUT0102-WS-FD	Water Spigot		27	Yes	11/10/2014	12	Routine Control Measures Only
DRINKING	DH-SCHOOL-OUT0103-WS-FD	Water Spigot		2.7	NO	N/A	N/A	
DRINKING	DH-SCHOOL-OUT0108-WS-FD	Water Spigot		320	Yes	11/10/2014	1.8	Routine Control Measures Only
DRINKING	DH-SCHOOL-OUT0109-WS-FD	Water Spigot		9.7	NO	N/A	N/A	
DRINKING	DH-SCHOOL-OUT0118-WS-FD	Water Spigot		1.5	NO	N/A	N/A	
DRINKING	DH-SCHOOL-OUT0136-WS-FD	Water Spigot		10	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM126-WFCA-FD	Water Fountain		non-detect	NO	N/A	N/A	
DRINKING	DH-SCHOOL-RM126-WFCB-FD	Coolers		1.4	NO	N/A	N/A	
DRINKING	DH-SCHOOL-OUT0131E-WS-F	Water Spigot		23	Yes	11/10/2014	2.1	routine Control Measures Only
DRINKING	DH-437-INF101-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-437-INF101-KA-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A	
DRINKING	DH-437-INF101-KB-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A	
DRINKING	DH-437-INF101-WFB-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A	
DRINKING	DH-437-INF102-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-437-INF102-KA-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A	
DRINKING	DH-437-INF102-KB-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A	
DRINKING	DH-437-INF102-WFB-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A	
DRINKING	DH-437-TOD103-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-437-TOD103-KA-FD	Kitchen Sink For Food Prep		1	NO	N/A	N/A	
DRINKING	DH-437-TOD103-KB-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A	

DRINKING	DH-437-TOD103-WFB-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A
DRINKING	DH-437-INF104-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A
DRINKING	DH-437-INF104-KA-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A
DRINKING	DH-437-INF104-KB-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A
DRINKING	DH-437-INF104-WFB-FD	Water Fountain (Bubbler)		1.6	NO	N/A	N/A
DRINKING	DH-437-TOD106-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD106-KA-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD106-KB-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD106-WFB-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD108-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD108-KA-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD108-KB-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD108-WFB-FD	Water Fountain (Bubbler)		1.1	NO	N/A	N/A
DRINKING	DH-437-TL110-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD111-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD111-KA-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD111-KB-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD111-WFB-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A
DRINKING	DH-437-HLW112-WFCA-FD	Water Fountain (Cooler)		non-detect	NO	N/A	N/A
DRINKING	DH-437-HLW112-WFCB-FD	Water Fountain (Cooler)		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD113-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD113-KA-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD113-KB-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD113-WFB-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD115-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD115-KA-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD115-KB-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A
DRINKING	DH-437-TOD115-WFB-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A
DRINKING	DH-437-KK-HHWA-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A
DRINKING	DH-437-KK-HHWB-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A
DRINKING	DH-437-KK-HHWC-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A
DRINKING	DH-437-KK-HHWD-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A
DRINKING	DH-437-KK-KSP-FD	Kitchen Sprayer		non-detect	NO	N/A	N/A
DRINKING	DH-437-OUT0103-WS-FD	Water Spigot		3.9	NO	N/A	N/A
DRINKING	DH-437-OUT0113-WS-FD	Water Spigot		2.2	NO	N/A	N/A
DRINKING	DH-437-OUT0136-WS-FD	Water Spigot		7.8	NO	N/A	N/A
DRINKING	DH-212-TOD101-HHW-FD	High Hand Washing (adults)		2.7	NO	N/A	N/A
DRINKING	DH-212-TOD101-LHWA-FD	Low Hand Washing Faucet (youth)		3.6	NO	N/A	N/A
DRINKING	DH-212-TOD103-HHW-FD	High Hand Washing (adults)		2	NO	N/A	N/A
DRINKING	DH-212-TOD103-LHWA-FD	Low Hand Washing Faucet (youth)		1.9	NO	N/A	N/A
DRINKING	DH-212-INF105-HHW-FD	High Hand Washing (adults)		3.3	NO	N/A	N/A
DRINKING	DH-212-INF105-K-FD	Kitchen Sink For Food Prep		2.4	NO	N/A	N/A
DRINKING	DH-212-TOD109-HHW-FD	High Hand Washing (adults)		1.6	NO	N/A	N/A
DRINKING	DH-212-TOD109-LHWA-FD	Low Hand Washing Faucet (youth)		1.4	NO	N/A	N/A
DRINKING	DH-212-TOD112-HHW-FD	High Hand Washing (adults)		1.4	NO	N/A	N/A
DRINKING	DH-212-TOD112-LHWA-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A
DRINKING	DH-212-STR117-HHW-FD	High Hand Washing (adults)		1.8	NO	N/A	N/A
DRINKING	DH-212-OUT0101-WS-FD	Spigot		9.2	NO	N/A	N/A
DRINKING	DH-212-OUT0105-WFB-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A
DRINKING	DH-212ANX-TODPS1-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A
DRINKING	DH-212ANX-TODPS1-K-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A
DRINKING	DH-212ANX-TODPS1-KSPA-FD	Kitchen Sprayer		non-detect	NO	N/A	N/A
DRINKING	DH-212ANX-TODPS1-KSPB-FD	Kitchen Sprayer		1	NO	N/A	N/A

DRINKING	DH-212ANX-TODPS1-LHWA-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS1-LHWB-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS1-LHWC-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS2-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS2-K-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS2-KSPA-FD	Kitchen Sprayer		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS2-KSPB-FD	Kitchen Sprayer		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS2-LHWA-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS2-LHWB-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS2-LHWC-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS3-HHW-FD	High Hand Washing (adults)		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS3-K-FD	Kitchen Sink For Food Prep		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS3-KSPA-FD	Kitchen Sprayer		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS3-KSPB-FD	Kitchen Sprayer		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS3-LHWA-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS3-LHWB-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS3-LHWC-FD	Low Hand Washing Faucet (youth)		non-detect	NO	N/A	N/A	
DRINKING	DH-212ANX-TODPS3-WFB-FD	Water Fountain (Bubbler)		non-detect	NO	N/A	N/A	